

Stainless Steel Bench Top Hole Bin/Chute Model: KRB10-NV FITTING INSTRUCTIONS

PARTS LIST:

- I x Lid
- I x Bag Holder
- I x Benchtop Rim
- I x Instruction Sheet

INSTALLATION

- I. Mark desired position and cut Ø 215mm hole in benchtop or work surface.
- 2. Insert rim into benchtop/work surface with preferred adhesive or silicone.
- 3. Attach bag to liner holder and insert
- 4. Fit Lid

