


MonoFlat LIN-X hinge ...

MonoFlat LIN-X 450 Instruction Manual PAT.P

Thank you for purchasing this MonoFlat LIN-X hinge by SUGATSUNE. Before proceeding with the installation, please read this instruction manual carefully for the best possible result and ensure your safety.




⚠WARNING –

- Failure to observe the following precautions may result in injury and/or lead to damage to surrounding cabinets or fittings.
- Choose suitable screws to ensure of proper installation of the cabinet and door.
- Ensure that door size, weight and material correspond to the specifications stated in this manual.
- Do not disassemble or modify the system.

■ Product Specification


| Door width | 400~500 mm | | | | | |
|----------------|---------------------|--|--|--|--|--|
| Door height | 600~900 mm | | | | | |
| Door thickness | 15∼24 mm | | | | | |
| Door weight | Max 7 kg (per door) | | | | | |

■Parts List




■Overall (unit: mm)

• Picture shows the left hand door use. (Right hand door use is symmetrical.)




■Overlay distance


- Side overlay as shown in Fig. 1 is:
 - 19 mm for mounting plate 230-P4W-32T
 - 14 mm for mounting plate 230-P4W-32T+5
- An opening clearance of 2mm is required on both sides of the door.



■Position of LIN-X Body

• Prepare the door as per Fig. 2 and Fig. 3





■Mounting Plate Position

 Prepare the sideboard for mounting plate installation as Fig. 4








Fig.4

■Installation


1 Mounting plate installation:





2 Cup Cover installation:




Ensure that the two o are pointing toward the edge of the door.








Ensure that the two LIN-X bodies are parallel by measuring both the base and mounting plate distances.



5 Door installation:




Ensure that the LIN-X body is securely attached to the mounting plates.



Adjustments


Adjustment screw (Horizontal)

Turn screw to adjust.




Adjustment screw (Depth)

Loosen screw, adjust the door and retighten screw.




Adjustment screw (Vertical)


Loosen screw, adjust the door and retighten screw.



Leveling Adjustment Screw Front

Loosen both screws, adjust the door and retighten screws.





SUGATSUNE KOGYO CO.,LTD.

Phone: +81 (0)3 3866 2260 Fax: +81 (0)3 3866 4447 E-mail: export@sugatsune.co.jp Website: www.sugatsune-intl.com

SUGATSUNE KOGYO (UK) LTD.

Phone: +44 (0)1491 680737 Fax: +44 (0)1491 60762 E-mail: sales@sugatsune.co.uk Website: www.sugatsune.co.uk

SUGATSUNE AMERICA, INC.

Phone: +1 310 3296373 Fax: +1 310 3290819 E-mail: sales@sugatsune.com Website: www.sugatsune.com

SUGATSUNE SHANGHAI CO., LTD.

Phone: +86 (0)21 3632 1858 Fax: +86 (0)21 3632 1868 E-mail: lamp@sugatsune.com.cn Website: www.sugatsune.com.cn

2009.05 PRINTED IN JAPAN 0445-1






MonoFlat LIN-X hinge ®

MonoFlat LIN-X600 Instruction Manual

PAT.P

Thank you for purchasing this MonoFlat LIN-X hinge by SUGATSUNE. Before proceeding with the installation, please read this instruction manual carefully for the best possible result and ensure your safety.



/ WARNING-

- Failure to observe the following precautions may result in injury and/or lead to damage to surrounding cabinets or fittings.
- Choose suitable screws to ensure of proper installation of the cabinet and door.
- Ensure that door size, weight and material correspond to the specifications stated in this manual.
- Do not disassemble or modify the system.


■ Product Specification

| Door width | 550∼650 mm | | | | | |
|----------------|---------------------|--|--|--|--|--|
| Door height | 600~900 mm | | | | | |
| Door thickness | 15~24 mm | | | | | |
| Door weight | MAX 9 kg (per door) | | | | | |

Parts List


| ① LIN-X body · · · · 2 p | CS. | ② Mounting | plate ···· | · 2 pcs. | ③ Co | nnecting | | ··· 1 pc. |
|-------------------------------|-----------|----------------|-------------------------|-----------|-------|-----------------|-----------------------------|---------------------------|
| | | | | | L=540 | Omm | | |
| Connecting plate cover 2 pcs. | ⑤ Cup cov | ver ·····2pcs. | © Counters tapping s | screw 3.5 | | ⑦ Binding screw | & tappir 3.5x15 | ng ···· 8pcs. |
| | | | A)June (A)June | · | | | Accounted (3) Accounted (3) | accessed (B) accessed (B) |

• Picture shows the left hand door use. (Right hand door use is symmetrical.) [unit:mm]




Installation

Mounting plate installation:





Cup cover installation:



Ensure that the two o are pointing toward the edge of the door.


S LIN-X body installation:






Ensure that the two LIN-X bodies are parellel by measuring both the base and mounting plate distances.


Connecting plate installation:




Door installation:



Ensure that the LIN-X body is securely attached to the mounting plates.





SUGATSUNE KOGYO CO.,LTD. Phone: +81 (0)3 3866 2260

F a x: +81 (0)3 3866 4447 E-mail: export@sugatsune.co.jp Website: www.sugatsune-intl.com SUGATSUNE KOGYO (UK) LTD.

Phone: +44 (0)1491 680737 F a x: +44 (0)1491 680762

E-mail: sales@sugatsune.co.uk Website: www.sugatsune.co.uk SUGATSUNE AMERICA, INC.

Phone: +1 310 3296373 F a x: +1 310 3290819 E-mail: sales@sugatsune.com Website: www.sugatsune.com SUGATSUNE SHANGHAI CO., LTD.

Phone: +86 (0)21 3632 1858 F a x: +86 (0)21 3632 1868 E-mail: lamp@sugatsune.com.cn Website: www.sugatsune.com.cn

ISO9001(Japan offices only) and ISO14001(Chiba production division and Logistic center only) certified

